

## Manual Sensor Beacon Go 500

### Features

- Sensors: acceleration, tilt, temperature, pressure, humidity, magnetic field, light
- Provision of the sensor values via blukii Sensor Beacon Protocol
- Three sensor packages can be selected / deselected via the blukii Configurator App, which transmit the sensor data one after the other according to the set advertising interval
  - Environmental (temperature, light, humidity, pressure)
  - Magnetometer (magnetic field)
  - Acceleration (acceleration and tilt)
- Bluetooth Low Energy® 4.2
- Management and setting of all parameters via blukii Manager and blukii Configurator App
- Individual pre-configuration possible (MOQ: 20 pieces)



### Intended Use

Sensor Beacons are Bluetooth transmitters that send sensor data and a unique ID to surrounding devices at certain intervals. They are used to identify places and objects.

- This document is part of the product. It contains important information for installation and operation. Store it carefully.
- Any other use than described in these instructions is not permitted. The manufacturer assumes no liability for personal injury or damage resulting from improper use.
- The product must not be modified
- If the product is damaged, it may no longer be used.
- Only operate the device within the technical specifications.
- The product should be operated in dry and dust-free locations.
- The product must not be exposed to strong mechanical loads.
- The beacon must be protected from strong heat.
- Do not operate the device near flammable gases and vapours.
- Do not remove any stickers or labels from the product. These contain important product and safety information.

### Assembly of Go 500 accessories

The Sensor Beacon Go 500 can be used alone or in combination with numerous accessories. To install the optional accessories, proceed as follows:

- Key Fob Go 500: Peel off the protective strip from the double-sided adhesive tape. Insert the Sensor Beacon with the label facing up into the Key Fob Go 500.
- Clip Go 500: Peel off the protective strip from the double-sided adhesive tape. Insert the Sensor Beacon with the label facing upwards into the Clip Go 500.
- Drop Go 500: Place the Sensor Beacon Go 500 in the ground. Put the top on slightly twisted and then turn it to the position that the outer contour of the top and bottom part are flush.

### Add Sensor Beacons in the blukii manager

To be able to configure and manage your Beacons in the blukii Manager, you have to add them to your blukii Manager account. Proceed as follows:

1. Log in to <https://manager.blukii.com/> with your blukii Manager account. If you don't have an account yet, you can create one for free.
2. In the "My blukiis" section, you can add new Sensor Beacons using the "+ ADD" button. Enter the activation code from your order in the corresponding field. By clicking on the "ADD TO MY BLUKIIS" button, the Sensor Beacons from your order will be assigned to your account.

## Management and configuration via blukii Manager and Configurator App

The cloud-based blukii Manager acts as a central tool for managing and configuring your Sensor Beacons. Device settings can be made here, which can then be transferred to the corresponding beacon using the blukii Configurator app. Changes made in the app are transferred to the blukii Manager.

To change the settings of your Sensor Beacon, proceed as follows:

1. Log in to <https://manager.blukii.com/> with your blukii Manager account.
2. In the "My blukiis" section, click on the blukii for which you want to change the settings.
3. Make the changes and apply them by clicking the "Save" button
4. Place your smartphone near the relevant beacon and start the blukii Configurator app
5. Select the corresponding blukii to get to the "Device Info" view. The orange cloud in the General section indicates that there are changed settings.
6. Now tap on the blue edit button at the bottom right and wait until the connection to the beacon has been established.
7. An Update area now appears in orange. Tap the "Update Device" button here to transfer the parameters changed in the blukii Manager to the beacon.
8. If you now exit the configuration view, a dark blue cloud shows that the data has been successfully synchronized and is up to date.

Parameter changes can also be made directly via the blukii Configurator app. To do this, proceed as follows:

1. Place your smartphone near the corresponding beacon and start the blukii Configurator app
2. Select the blukii for which you want to make changes
3. Then tap in the "Device Info" view on the blue edit button at the bottom right and wait until the connection to the beacon has been established.
4. Make the changes and apply them by clicking on the "Save" button
5. After leaving the "Configuration view", the changes are transferred to the blukii Manager

## Changing batteries

To change the battery of your Sensor Beacon Go 500, please proceed as follows:

1. Open the battery cover and remove the battery.
2. Pay attention to the battery instructions in the next section
3. Insert the new battery with the positive pole on top. Push the battery diagonally against the side battery contact before pushing it completely down.
4. Close the battery cover

## Battery notes

- **Do not use rechargeable batteries!**  
Rechargeable Batteries usually have a higher internal resistance and lower voltages. This can lead to incorrect runtime estimation and reduced operating time.
- **Use high quality batteries!**  
A Panasonic CR3032 button cell is suitable for operating your Sensor Beacon Go 500
- **Risk of explosion!**
  - Do not recharge, short-circuit or disassemble batteries!
  - Immediately remove empty batteries from the Sensor Beacon Go 500
  - Keep batteries away from children and avoid contact with eyes, skin and mucous membranes. If you come into contact with battery acid, wash out immediately with clear water and consult a doctor.



## Help in case of errors

Error	Cause	Remedy
Sensor Beacon is not detected in the Configurator App	The slider for the RSSI value is too low	Raise the threshold to get more distant beacons on the display
Sensor Beacon is not detected in the Configurator App	The Sensor Beacon is out of range	Make sure that the beacon is in the immediate range of your smartphone
The connection with blukii Configurator App fails. Notification: blukii connection failed!	The Sensor Beacon is not assigned to your blukii Manager account	Add the blukii to your blukii Manager account. See section "Add Sensor Beacons in the blukii Manager"

## Technical specifications

### Advertising

Beacon protocols	iBeacon, blukii Sensor Beacon Protocol
Advertising interval	0,1s to 10s (adjustable) Default: 1s

### Radio

Standard	Bluetooth 4.2 (Bluetooth Low Energy)
Controller	Texas Instruments CC2640
Range	Up to 100m
Frequency range	2.402 to 2.480GHz
TX-Power (adjustable)	High(5dBm) / Medium(0dBm) / Low(-9dBm) / Lowest(-20dBm)
Antenna	Customized OnBoard SMD-Antenna

### Sensors

Acceleration / Tilt	0-2g (3-Axis)
Temperature	-40°C to +85°C
Pressure	300-1100hPa
Humidity	0 to 100% (RH)
Magnetic field	+/-1,6mT
Light	0 to 65k lx

### Battery

Type	Lithium-manganese-dioxide
Model	Panasonic CR3032 3V/500mAh
Capacity	50mAh
Replaceable	Yes
Lifetime at Advertising interval 0,3s (TX-Power: +5dBm)	0,3 years
Lifetime at Advertising interval 1s (TX-Power: +5dBm)	1,1 years

### Mechanical specifications

Enclosure material	Copolyester
Colour	white
Protection Class	IP20
Flammability rating	UL94HB
Dimensions	32x9mm
Weight	15g

### Environmental requirements

Operating temperature	-20°C to +60°C (Lifetime drops sharply under 0°C )
-----------------------	--

### Certifications

CE (2014/53/EU, 2011/65/EU)
-----------------------------

## Disposal

According to European guidelines and the German Electrical and Electronic Equipment Act (ElektroG), Sensor Beacons must not be disposed of with household waste.

After use, dispose of Sensor Beacons at a responsible collection point for old electrical and electronic devices

Sensor Beacons contain batteries. These batteries must not be disposed of with household waste. Please take them to an appropriate collection point in an unloaded state.



## CE Declaration

Schneider Schreibgeräte GmbH declares herewith that the device is compliant with the basic requirements and the relevant rules in directives 2014/53/EU und 2011/65/EU.



## Service

More information about your Sensor Beacon:

Contact: <https://www.blukii.com/en/contact>  
Further documents: <https://www.blukii.com/en/resources>  
Phone: +49 (0) 7729 888 4225  
Mail: [support@blukii.com](mailto:support@blukii.com)

### **Business area blukii:**

Schneider Schreibgeräte GmbH  
blukii  
Unterm Dorf 184/1  
D-78144 Schramberg

### **Headquarters Schneider Schreibgeräte**

Schneider Schreibgeräte GmbH  
Schwarzenbach 9  
D-78144 Schramberg